



Operating Instructions

863 Valley View Road, Eighty Four PA 15330

Tel: 724-941-9701 Fax: 724-941-1369

www.skcinc.com

Stick-to-it

Lift Tape for Surface Sampling



1. Remove slide from slide mailer.
2. Document the sample location and other required information for the laboratory.
3. Peel off protective liner from slide to expose adhesive. (Pull liner from top down for best results.)
4. Place slide adhesive side down on the surface to be sampled.
5. Gently press down to ensure contact is made.
6. Carefully remove slide from surface and place back into slide mailer.
7. Send slide to laboratory for analysis.

Notice: This operating instruction may not address all safety concerns (if any) associated with this product and its use. The user is responsible for determining and following the appropriate safety and health practices and regulatory limitations (if any) before using the product. The information contained in this document should not be construed as legal advice, opinion, or as a final authority on legal or regulatory procedures.

Form #40065 Rev 0404