

Air-Met Sales/Service Air-Met Rental P: 1800 000 744

P: 1300 137 067 E: hire@airmet.com.au W: www.airmet.com.au



Operating Instructions



863 Valley View Road, Eighty Four PA 15330 Tel: 724-941-9701 Fax: 724-941-1369 www.skcinc.com

Calidaptor Cat. No. 391-01

To use the 391-01 Calidaptor with an IOM Sampler:

- 1. Push IOM through hinged bracket and place inlet against foam ring.
- Clamp IOM in place with plastic clamping screw until foam ring 2. compresses by 1 mm. Ensure IOM inlet is centered.
- 3. Screw supplied hose barb into threaded hole in calibration adapter inlet.
- Use a length of flexible tubing to connect hose barb to calibrator outlet. 4.
- Connect IOM outlet to the inlet of a sample pump. 5.
- Adjust pump flow until desired flow reading appears on flowmeter. 6.

For additional information, contact SKC Technical Support at skctech@skcinc.com

SKC is an ISO 9001 Registered Manufacturing Company

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to http://www.skcinc.com/warranty.asp.